

6314581



6314581

2013 DODGE RAM 1500

2013 DODGE RAM 1500

2013 DODGE RAM 1500 Torch Series Grille

TOOLS REQUIRED:

- Screwdriver
- Flat Screwdriver
- Diegrinder

PARTS LIST:

- (1) Mesh Grille
- (10) L-Brackets
- (10) 6/32 Nylon Lock Nuts

Install time: 45 Mins.

For off-road use only

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

- Remove Clips to Remove the Plastic Cover. (Fig. 1)
- Remove the Grille Shell.
- Remove the Plastic Grille Support. (Fig. 2)
- Unclip the Plastic Grille Covers with a Flat Screwdriver. (Fig. 3)
- Unclip the Grilles from the Grille Shell and Remove. (Fig. 4)
- With a Diegrinder, Start Cutting the Center and Vertical Bars on the Grille Shell as close to the Outer Grille Shell as possible. (Fig. 5)
- Place the Mesh Grille onto the Grille Shell and Place an L-Bracket and Nylon Lock Nut onto the Threaded Studs. (Fig. 6)

INSTALLATION COMPLETE

